

## IMPORTANT ASSEMBLY INSTRUCTIONS

Mount the washer with the burr side facing the bolt head and the smooth side facing the faceplate. The sharp edges of the burr could damage the aluminum faceplate. Max torque for all Firefly stem bolts is 6Nm but always refer to handlebar and steerer torque specs and torque bolts to the lowest Nm.

