

MOUNTAIN FIT FORM



KEVIN WOLFSON
LEAD FRAME DESIGNER

617.825.3473
KEVIN@FIREFLYBICYCLES.COM

FIREFLY BICYCLES
117 BOSTON ST
DORCHESTER, MA
02125

FIREFLYBICYCLES.COM

CONTACT INFORMATION AND FRAME SPECIFICATIONS

Name

Shipping Address

Primary Phone Number

Email

STYLE (FRAME ONLY)

- XC/Trail // \$4300 27.5+ // \$4600 Fat // \$4600

WHEEL INFO

- 29" 27.5" 26"
- Max tire size for new bike

SHIFTING

- Geared
- Single Speed

BRAKES

- Hydraulic Disc Cable Disc

BOTTLE CAGES

- 0 1 2 3

EXTRA FRAME OPTIONS

- Suspension forks from Fox, Rock Shox, Cannondale, and many others. // Call for quote
- Internal Di2 routing // \$200 Internal brake routing // \$350 Internal dropper post routing // \$250
- Pressfit30 BB // \$75
- Carbon seat tube // \$1000
- Rack mounts Fender mounts
- S&S couplers // \$1000
- Belt drive // \$300

FINISH

- Bead-blasted Brushed// \$300 Custom

LOGOS

- Decals Brushed/blasted Anodized// \$200

Contact us or [visit our finish options page](#) for more details about finish options.

PARTS KIT

We offer a full range of parts kits and components to complete your dream bike.

Email kevin@fireflybicycles.com for more details.

CURRENT BIKE INFO

Please take all measurements in cm

MAKE

MODEL

YEAR

THE FOUR KEY CONTACT POINTS

A: SADDLE HEIGHT

Measure from the center of the bottom bracket to the top-center of the saddle.

B: SADDLE SETBACK

This is best measured with a plumb bob (any long string with a weight on it will do).

Place the string on the tip of the saddle and drop the weight below the bottom bracket.

After it steadies, measure horizontally from the string to the center of the bottom bracket.

C: REACH

Measure from the tip of the saddle to the top-center of the bars.

D: HANDLEBAR DROP

Measure vertically from the top of the saddle to the ground.

Then measure vertically from the top-center of the bars to the ground.

Subtract the second measurement from the first.


OTHER BIKE SPECS

Horizontal TT length

Stem length and angle

Headset Spacers (in mm)

Saddle Choice



BODY INFO

Please take all measurements in cm. (Image courtesy of BikeCAD)

WEIGHT

AGE

A: HEIGHT

B: TOTAL BODY LENGTH

Your sternal notch is the notch at the base of your neck. Stand up straight with your feet at shoulder width. Measure from your sternal notch to the floor.

C: INSEAM

Still standing with your feet shoulder width apart, hold a book between your legs and parallel to the ground. Pull the spine of the book up into your perineum with the pressure of a saddle. Measure from book's spine to the ground.

Check this measurement a couple of extra times, it is the most difficult to take accurately.

D: ARM LENGTH

Your acromion process is the outermost bone in your shoulder. Hold onto a pen and hold your arm as straight as possible at a 45° angle. Measure from the acromion process to the pen.

E: SHOULDER WIDTH

Measure from one acromion process to the other.

