

KEVIN WOLFSON | LEAD FRAME DESIGNER

423 Pleasant St, Melrose, MA 02176 | 617-825-3473 Send completed form to kevin@fireflybicycles.com

CONTACT INFORMATION & FRAME SPECIFICATIONS			
Name			
Shipping Address			
Primary Phone Number			
Email			
MATERIAL			
Titanium // \$5200	Ti-Carl	Ti-Carbon // \$6900	
FORK CHOICE			
ENVE AR Disc	Whiske	Whiskey No. 9 Rd+ (select for bikes with shorter top tubes, 55cm and below)	
Firefly Road Plus // \$15	25 Other	Other	
WHEEL INFO			
650b 700c	Both (all disc bik	es fit both) Ma	ax tire size for new bike
SHIFTING			
Mechanical 2x	Mechanical 1x	Wireless	Internal Di2 // \$200
BRAKES			
Disc (standard)	Cantilever	Linear pu	П
BOTTLE CAGES			
0 1	2 3		
EXTRA FRAME OPTIONS Contact us or visit our <u>Technology page</u> for more details about our frame options			
T47 threaded BB (included with Ti-Carbon) // \$75			Internal brake routing // \$350
Pressfit30 BB (included with Ti-Carbon) // \$75 Fender mounts			
Tapered head tube for integrated headset // \$100			3D printed chainstay yoke for max tire clearance
Rack mounts			and shortest possible chainstay length // \$200
Pump peg			Bosch Performance pedal assist motor mount // \$800 Complete builds starting at \$9200
Li travel couplers // \$1300			(only available on full ti frames sold within the US)
Proprietary tapered carbon integrated seatpost // \$800			
Custom frame bag mounts // \$100			
FINISH OPTIONS			
Bead-Blasted	Brushed // \$300	Custom	
LOGOS			
Decals	Brushed/Blasted	Anodized	// \$200
Contact us or visit our <u>Finish Options page</u> for more details about finish options.			

PARTS KIT

We offer a full range of parts kits and components to complete your dream bike. Email <u>kevin@fireflybicycles.com</u> for more details.



MAKE

MODEL

YEAR

THE FOUR KEY CONTACT POINTS

Please take all measurements in cm

A. SADDLE HEIGHT

Measure from the center of the bottom bracket to the top-center of the saddle.

B. SADDLE SETBACK

This is best measured with a plumb bob (any long string with a weight on it will do). Place the string on the tip of the saddle and drop the weight below the bottom bracket. After it steadies, measure horizontally from the string to the center of the bottom bracket.

C. REACH


Measure from the tip of the saddle to the top-center of the bars.

D. HANDLEBAR DROP

Measure vertically from the top of the saddle to the ground. Then measure vertically from the top-center of the bars to the ground. Subtract the second measurement from the first.

OTHER BIKE SPECS

Horizontal TT Length Stem Length & Angle Headset Spacers *(in mm)* Saddle Choice





AGE

Please take all measurements in cm

A. HEIGHT

B. TOTAL BODY LENGTH

Your sternal notch is the notch at the base of your neck. Stand up straight with your feet at shoulder width. Measure from your sternal notch to the floor.

C. INSEAM

Still standing with your feet shoulder width apart, hold a book between your legs and parallel to the ground. Pull the spine of the book up into your perineum with the pressure of a saddle. Measure from book's spine to the ground.

Check this measurement a couple of extra times, it is the most difficult to take accurately.

D. ARM LENGTH

Your acromion process is the outermost bone in your shoulder. Hold onto a pen and hold your arm as straight as possible at a 45° angle. Measure from the acromion process to the pen.

E. SHOULDER WIDTH

Measure from one acromion process to the other.

